

## MANUAL

Thank you for choosing **MOBIKICK**! We hope you will have many fun and energizing outdoor experiences with it.

**MOBIKICK** is the ultimate device for getting around on snow and ice, but for safety reasons it is prohibited to use it in ski slopes.

When fastening **MOBIKICK** to the downhill skies you should pay attention to the following:

- You get the most out of **MOBIKICK** with skies that are over 180 cm. Skies of this length give the best bearing capacity even in heavier snow.
- Along with the package you will find wooden anti-slip strips. Attach them to the skies to prevent your feet from slipping off. Fasten the straps to the cleaned surface according to the picture. To ensure that the glue really sticks to the ski, warm the glue for example over a candle.
- Fasten the **MOBIKICK** one ski at a time. Please note that the ski is slightly tilted when it is locked. To unlock the skies, open both bindings at simultaneously.
- If you wish to use **MOBIKICK** in rough or hilly terrain, please tighten the bindings to maximum to prevent the skies from coming off. **Remember to adjust the bindings back to normal if you are also using the skies for skiing.**

### Tips on how to get started with the MOBIKICK

Learn the kicking technique right from the beginning. The foot on the ski should stay close to the binding. Keep the main body weight over the handlebar. Kick and let your entire body follow the powerful move. Change the kicking foot after 5–10 kicks. We recommend you use the anti-slip strips especially on slippery surfaces.

Steer by lifting the handlebar. **Please practise steering before heading to hilly terrains.**

**Scanmobi Oy**  
www.scanmobi.fi  
[info@scanmobi.fi](mailto:info@scanmobi.fi)  
+358 500-697156

